

How to set time and date on a two-hand watch

1. Remove the watch from your wrist

Do not wear your watch while you wind and set it. If you leave your watch on, you risk winding your watch at an awkward angle and, in turn, damaging the internal components and potentially loosening the crown.

2. Unscrew crown (10 ATM or higher watches only)

If your watch is 10 ATM (or higher) water resistant, you probably first have to unscrew the crown, by turning it counter-clockwise. If you cannot turn the crown clockwise, the crown is screwed down.


3. Make sure the watch is running

If it has been a long time since you have worn your watch, you'll want to make sure it is running before you set the time:

- If your **quartz watch** does not run, the battery needs to be changed first.
- Fully wind a **handwinding watch** before you set the time/date.
- To wind your **automatic watch**, gently tilt it forwards and backwards to move the rotor.
- Leave your **solar watch** under a light source to start it running.

Setting the time

4. To set the time, pull the crown fully out (2 clicks)




To set your watch's time, simply pull the crown out to the furthest position from the watch base. The hands stop to help you accurately set the time.

5. Check the correct time

Before setting the time, make sure you have access to a (digital) reference clock, based on atomic timekeeping. For example on the website <https://time.is> you can find the correct time for your region.

6. Set the time



Gently turn the crown clockwise (or away from you) until you set the correct time.

7. Screw the crown back in

If applicable, screw the crown down to ensure it is pressurized and water-tight.


If you overshoot your desired time, do not turn the crown counter-clockwise to go back. Turning the crown counter-clockwise will force and damage the watch's movement. Instead you will have to continue winding clockwise until you come back around to the correct time again and repeat the time setting process as above.

Setting the date

To set the day and or date on your watch, first follow steps 1-3.


On most watches, the date changes automatically between 9 PM and 3 AM. To avoid damaging the date gears when they are in motion it is advisable to set the date outside this time frame before 12.00 AM.

8. Set the time to 6.30




To make sure the watch changes the date between 9 PM and 3 AM, first set your watch to 6.30 following step 4-6.

9. Set the day-date to one day before today




On most watches, you can set the day and date by pulling the crown 1 click.



Turn the crown *clockwise* (away from you) to change the date. Turn the crown *counterclockwise* (towards you) to change the day.

Set the day and date to the day BEFORE today. By setting the day and date before the day it actually is, you can then manually push the hours forward until the day swaps over to the next day. When it does, you will have made sure your watch is set to AM.

10. Set the correct time (and date)



Pull the crown all the way out (2 clicks) and turn the crown clockwise (away from you) until you see the day-date change to the AM of TODAY. Now set the watch to the correct time.

Push the crown fully in and screw down if applicable.

Problem solving

Automatic watch does not run or is slow

If, after setting the correct time on your watch it has not immediately started running or is slow, it is advisable to have your watch checked by a licenced watch maker.

The date changes to early or too late

The date on the watch was not set to the correct AM time. Repeat steps 8-10.